

Kit of screws and nuts for panel mounting



Includes

Kit comprising: - 4 M10×20 screws - 2 M10 nuts - 2 captive M10 nuts

Highlight

Workstation ergonomics

Description	
Reference	Includes
PLA VEGM	Kit comprising: - 4 M10×20 screws - 2 M10 nuts - 2 captive M10 nuts
PLA VEPM	Kit comprising: - 2 M8×20 mm screws - 1 M8 nut - 1 captive M8 nut
PLA VEAF	Kit comprising: - 12 M6×20 mm rectangular head screws - 12 M6 nuts for mounting an accessory. a wall fitting and an ALTO assembly
PLA VEWF	Kit of screws and nuts: - 4 M6×20 mm screws - 4 M6 nuts

